

NAME

gotox - a program to operate a rotor of a satellite dish.

SYNOPSIS

gotox [*options*]

DESCRIPTION

This manual page documents briefly the **gotox** commands.

gotox is a program to operate a rotor set to tune a satellite dish.

OPTIONS

-h print this help text

-d degrees

Goto the specified angle. Positive value for East rotation, negative value for West rotation on Northern Hemisphere (default 0)

-a number

use given adapter (default 0)

-f number

use given frontend (default 0)

-t seconds

leave power on to rotor for at least specified seconds of time (default 30)

This manual page was written by Uwe Bugla <uwe.bugla@gmx.de>.