

NAME

`fw_setenv` - Tool for modifying the environment for the bootloader U-Boot

SYNOPSIS

`fw_setenv name [value]`

DESCRIPTION

fw_setenv is a simple tool for modifying either the environment for the bootloader U-Boot. If the variable already is set in the environment it is updated, otherwise it is created and set. If only one argument is given, variable name, the corresponding variable is deleted.

FILES

`/etc/fw_env.config`
Configuration file for `fw_setenv`.

SEE ALSO

[fw_printenv\(8\)](#)

AUTHOR

Wolfgang Denk <wd@denx.de>

This manual page was written by Per Andersson <avtobiff@gmail.com>