

NAME

sensors-conf-convert - sensors configuration conversion

SYNOPSIS

sensors-conf-convert < */etc/sensors.conf* > */etc/sensors3.conf*

DESCRIPTION

The purpose of the **sensors-conf-convert** tool is to convert *sensors.conf* from the lm_sensors version 2 format to the lm_sensors version 3 format.

The old configuration file is read from the standard input and the new one is written to the standard output.

SEE ALSO

[sensors\(1\)](#), [libsensors\(3\)](#)

AUTHOR

Jean Delvare