

**NAME**

`hpsa` - HP Smart Array SCSI driver

**SYNOPSIS**

```
modprobe hpsa [ hpsa_allow_any=1 ]
```

**DESCRIPTION**

**hpsa** is a SCSI driver for HP Smart Array RAID controllers.

**Options**

*hpsa\_allow\_any=1*: This option allows the driver to attempt to operate on any HP Smart Array hardware RAID controller, even if it is not explicitly known to the driver. This allows newer hardware to work with older drivers. Typically this is used to allow installation of operating systems from media that predates the RAID controller, though it may also be used to enable **hpsa** to drive older controllers that would normally be handled by the **cciss(4)** driver. These older boards have not been tested and are not supported with **hpsa**, and **cciss(4)** should still be used for these.

**Supported hardware**

The **hpsa** driver supports the following Smart Array boards:

- Smart Array P700M
- Smart Array P212
- Smart Array P410
- Smart Array P410i
- Smart Array P411
- Smart Array P812
- Smart Array P712m
- Smart Array P711m
- StorageWorks P1210m

**Configuration details**

To configure HP Smart Array controllers, use the HP Array Configuration Utility (either **hpacuxe(8)** or **hpacucli(8)**) or the Offline ROM-based Configuration Utility (ORCA) run from the Smart Array's option ROM at boot time.

**FILES****Device nodes**

Logical drives are accessed via the SCSI disk driver (**sd(4)**), tape drives via the SCSI tape driver (**st(4)**), and the RAID controller via the SCSI generic driver (**sg(4)**), with device nodes named `/dev/sd*`, `/dev/st*`, and `/dev/sg*`, respectively.

**HPSA-specific host attribute files in /sys**

`/sys/class/scsi_host/host*/rescan`

This is a write-only attribute. Writing to this attribute will cause the driver to scan for new, changed, or removed devices (e.g., hot-plugged tape drives, or newly configured or deleted logical drives, etc.) and notify the SCSI midlayer of any changes detected. Normally a rescan is triggered automatically by HP's Array Configuration Utility (either the GUI or the command-line variety); thus, for logical drive changes, the user should not normally have to use this attribute. This attribute may be useful when hot plugging devices like tape drives, or entire storage boxes containing preconfigured logical drives.

`/sys/class/scsi_host/host*/firmware_revision`

This attribute contains the firmware version of the Smart Array.

For example:

```
# cd /sys/class/scsi_host/host4
# cat firmware_revision
7.14
```

**HPSA-specific disk attribute files in /sys**

*/sys/class/scsi\_disk/c:b:t:l/device/unique\_id*

This attribute contains a 32 hex-digit unique ID for each logical drive.

For example:

```
# cd /sys/class/scsi_disk/4:0:0:0/device
# cat unique_id
600508B1001044395355323037570F77
```

*/sys/class/scsi\_disk/c:b:t:l/device/raid\_level*

This attribute contains the RAID level of each logical drive.

For example:

```
# cd /sys/class/scsi_disk/4:0:0:0/device
# cat raid_level
RAID 0
```

*/sys/class/scsi\_disk/c:b:t:l/device/lunid*

This attribute contains the 16 hex-digit (8 byte) LUN ID by which a logical drive or physical device can be addressed. *c:b:t:l* are the controller, bus, target, and lun of the device.

For example:

```
# cd /sys/class/scsi_disk/4:0:0:0/device
# cat lunid
0x0000004000000000
```

**Supported ioctl() operations**

For compatibility with applications written for the [cciss\(4\)](#) driver, many, but not all of the ioctls supported by the [cciss\(4\)](#) driver are also supported by the **hpsa** driver. The data structures used by these ioctls are described in the Linux kernel source file *include/linux/cciss\_ioctl.h*.

**CCISS\_DEREGDISK, CCISS\_REGNEWDISK, CCISS\_REGNEWD**

These three ioctls all do exactly the same thing, which is to cause the driver to rescan for new devices. This does exactly the same thing as writing to the hpsa-specific host rescan attribute.

**CCISS\_GETPCIINFO**

Returns PCI domain, bus, device and function and board ID (PCI subsystem ID).

**CCISS\_GETDRIVER**

Returns driver version in three bytes encoded as:

(major\_version << 16) | (minor\_version << 8) | (subminor\_version)

**CCISS\_PASSTHRU, CCISS\_BIG\_PASSTHRU**

Allows BMIC and CISS commands to be passed through to the Smart Array. These are used extensively by the HP Array Configuration Utility, SNMP storage agents, and so on. See *cciss\_vol\_status* at [Unknown](#) for some examples.

**SEE ALSO**

[cciss\(4\)](#), [sd\(4\)](#), [st\(4\)](#), [cciss\\_vol\\_status\(8\)](#), [hpacucli\(8\)](#), [hpacuxe\(8\)](#),

[Unknown](#), and *Documentation/scsi/hpsa.txt* and *Documentation/ABI/testing/sysfs-bus-pci-devices-cciss* in the Linux kernel source tree

**COLOPHON**

This page is part of release 3.74 of the Linux *man-pages* project. A description of the project, information about reporting bugs, and the latest version of this page, can be found at <http://www.kernel.org/doc/man-pages/>.